

MENU 1

[illegible]

1-01	0	PROG 7
	1	PROG 1

1-02	0	60 min.
	1	30 min.
	2	15 min.

1-06	0	 HEAT-COOL
	1	 HEAT

1-08	0	Yes
	1	No

1-09	0	No
	1	Yes

MENU 2

1. Press the power button.

2. Press the 'R' button.

3. Press the '1' button.

4. Press the '2' button.

5. Press the 'OK' button.

6. Press the '2' button.

7. Press the 'OK' button.

8. Press the '1' button.

9. Press the 'OK' button.

10. Press the '1' button.

11. Press the 'OK' button.

12. Press the '1' button.

13. Press the 'OK' button.

2-01

0	Lock icon * : 5°C < > 30°C * : 5°C < > 16°C
1	Lock icon 16°C < * Heat > 22°C 13°C < ☾ Heat > 19°C 21°C < * Cool > 27°C 24°C < ☾ Cool > 30°C

2-08

Base de temps de régulation / Regulation time base / Base de tiempos de regulación /	
--	--

43.7

10.1

EXIT

2-08	Base de temps de régulation / Regulation time base / Base de tiempos de regulación / Base de tempo de regulação / Base di tempo di regolazione / Zeitbasis für die Einstellung / Podstawa czasu regulacji / Basis voor instellingstijd / Báze doby regulace / Bas för inställningstid / Tidsbasis for regulering / Tidsenhet for regulering / Lämmönsäätelyn aikayksikkö / 调节时基
2-09	 Change-over


2-01	0	  * : 5°C <  > 30°C * : 5°C <  > 16°C
	1	 16°C <  Heat> 22°C 13°C <  Heat> 19°C 21°C <  Cool> 27°C 24°C <  Cool> 30°C  PROG

2-02 - 5°C < > +5°C

2-04	0	
	1	

2-08	30	Minutes
	45	Minutes
	60	Minutes

2-09	0	 = COOL mode
Change-over	1	 = HEAT mode



R-01	0	No
	1	Yes

R-02	0	No
	1	Yes

[illegible]

RESET

